

FEATURES

AVAILABLE FORMATS

- 20°** High gloss surfaces such as automotive paint finish, polished metals and plastics
- 45°** Speciality finishes such as ceramics, textiles and anodised aluminium
- 60°** Universal gloss measurement angle for all applications
- 20°/60°** Measure all mid to high gloss surfaces with both angles simultaneously

CONTINUOUS READ

Assess gloss variations on a large surface in seconds

FLEXIBLE CALIBRATION

Calibrate on a standard that matches your sample for improved gloss control. Additional standards available from matt to mirror finish

STATISTICAL ANALYSIS

Automatic calculation of batch statistics

DOWNLOAD TO PC

Download your results to Novo-Soft for further analysis, reporting and storage

EXTRAS

FREE EXTENDED WARRANTY

Register for a two year comprehensive guarantee

FREE LIGHT SOURCE WARRANTY

Guaranteed for the life of the instrument

UKAS CALIBRATION

Instruments and calibration tiles are available with ISO 17025 certification

CALIBRATION AND SERVICE

Fast and economic service via our global network of accredited calibration and service centres

LOCAL AGENT

ACCESSORIES

- BAM traceable calibration standard
- Calibration tile cleaning kit
- Quick-start guide
- Data cable
- Protective instrument case
- Novo-Soft™ QA software CD
- Full instruction manual in PDF format
- Screwdriver

POWER OPTIONS:

- Battery operated – 5 x AAA high power batteries
- Rechargeable – mains charger



SPECIFICATIONS

Resolution	0.1 GU
Repeatability	0.2%
Reproduceability	0.5%
Battery life	15,000+ readings
Languages	EN, FR, D, NL, ESP, IT, TK, CZ

CONFORMITY

Standards:

20°/60° BS EN ISO 2813 ASTM D523 ASTM D2457 DIN 67530 JIS 8741	45° ASTM C346 BS6161 JIS 8741
--------------------------------------------------------------------------------------	-----------------------------------------------



Certificate no: FM 29741
BS EN ISO 9001: 2000



Beeching Road, Bexhill-on-Sea, East Sussex, TN39 3LG, UK
T +44 (0) 1424 214291 F +44 (0) 1424 730600
enquiries@rhopointinstruments.com www.rhopointinstruments.com